


LRA-VPRX MANUAL

PARTS & FUNCTION DOOR BELL



MOUNTING



Or



POWER

1. Slide to open the battery cover
2. Insert 2 AA batteries
3. Close the battery cover.



CODE PAIRING & MELODY SELECTION

- Step 1: Insert the battery into the transmitter to be used (Doorbell button)
- Step 2: Insert the batteries into the receiver (pager unit).
- Step 3: Enter pairing mode for the receiver (pager unit). Press & hold the ● zone selector button for 3 seconds. The LED in zone #1 will flash.
- Step 4: Press the ● zone selector button again to move to the zone you wish to pair with. Press the ♪ melody selector button to scroll through the melodies. Once you hear a melody you prefer, do not press any button as the melody is set for that zone.
- Step 5: Once the zone & melody are selected, press the Doorbell button once to pair. If successful, the receiver (chime unit) will generate two short tones. Press the ● zone selector button to exit the pairing mode, the system is now ready to use.

To stop the Chime whilst it is alerting press the reset button

Clear the transmitter on the Chime memory

First, press and hold the ● button for 3 seconds to enter the pairing mode. Press the ● button to move to the zone which is to be deleted. Press and hold the ● and ♪ buttons together for 3 seconds. The receiver will generate a tone to indicate the transmitter on this zone has been deleted.

Change the melody in desired zone

First, press and hold the ● button for 3 seconds to enter the pairing mode. Press the ● button to move to the zone then press the ♪ button to select the melody required. Press the ● button until the pairing mode is exited.

Battery low indicator

If a zone LED light is blinking, it indicates that the battery is low for this transmitter. You must replace the battery as soon as possible. If the receiver beeps every 5 seconds, this indicates the receiver batteries are low. You must replace the batteries of the receiver.

TECHNICAL SUPPORT

If you need assistance with the operation of this product, please contact us. You can reach us by phone at 904-245-1184 from 8:00AM to 5:00PM Monday through Friday, EST. You may also reach us via email at info@safeguardsupply.com

WARRANTY INFORMATION

The product you have purchased is guaranteed against defects in workmanship and materials for a period of one year from the date of purchase. Warranties implied by law are subject to the same time period limitation.

For a detailed warranty policy, please visit our website by visiting:

www.safeguardsupply.com/warranty.htm

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.



Made in China - 2016